



Saber-6 Wireless Crane Radio with Access Control

Model SAB600, Version 1.0



User Notes

V1.0: 10/09/2015

© CASWA Pty Ltd – 2015



1 Introduction

The Saber-6 V1.0 (SAB600) crane radio is currently a Magnatek Flex6-EX radio integrates with a Sole Digital AccessPack application board. Therefore, for details on the basic functionality of the radio, please refer to the Magnatek manual that accompanied the radio.

The AccessPack board mounted internally within the SAB600/Flex6EX behaves exactly like any other AccessPack fitted internally or externally to other crane radio remotes. Details on this behaviour, as well as comprehensive commissioning processes or operating functionality can be found in the following document:

<http://www.soledigital.com.au/docs/AccessPack.pdf>

This product note will only refer to behaviour that is specific to the SAB600/Flex6Ex setup.

2 Commissioning

The SAB600/Flex6 units supply by your vendor will be shipped preconfigured and will be accompanied by a AccessPack RFID card that can be used during installation. This card will only be valid for a few months after shipment. After this time, cards will need to be programmed as discussed in the AccessPack User manual in order to connect to the SAB600/Flex6EX.

3 Operating

Before presenting your card, make sure the E-Stop is released and the radio dial in the ON position.

Move the radio to wake up the AccessPack.

Lights marked A and D will flash alternately for a few seconds whilst the AccessPack is looking for a valid card. (They will then stop and the radio will go to sleep until it is again 'Woken' by movement.)






To start the radio, present the AccessPack card to the back of the radio in the following position:



If a valid card is presented, the A and D lights will flash quickly together for a few seconds and then the Status light will go green for a short time.



The radio is now ready to use as normal.

If the radio is not used for a period of time, the AccessPack will disable the radio and you will need to present the card again to keep using the radio.