

Tech Note

Title: Installing on DITS-CA
Product : AccessPack
Author: PK
Date: 13/6/13

1 DESCRIPTION

SLBs DITS CA machines are controlled by a laptop computer, and use a PC kit to work with AccessPack.

Because the laptops were configured some time ago and have no kinternet connection, several updates and drivers must be installed before the AccessPack software will work. For convenience, we have collected all of these into a single archive: <http://www.soledigital.com.au/software/ditsca.zip>

Copy these files to a memory stick. You will also need a short USB extension cable (I normally steal one from the surface techs) because the USB plug may not fit properly into the side of the laptop.

Copy all the files from the downloaded archive to a folder on the DITS-CA laptop.

First we need to update the windows installation on the laptop.

- Run the dotnetfx35 install first. This will update the windows software on the laptop.
- Then run the CP210x_VCP_Windows\CP210xVCPInstaller_x86.exe to load the USB drivers for the AccessPack.

Finally install our application by running setup.exe

Test the installation by running start->programs->caswa->appprotect.

You should see a window like this:



Appear in the top left corner of the screen.

The background will change to this:



When the AccessPack is logged in

If you have any problems, (you might need to invert the e-stop output of the AccessPack), then you can just power off the laptop and power it back on.

Once you have it working then put a shortcut to this program in the startup folder.

2 PICTURES

